PLATINUM SIGNS

MAILER BOX ASSEMBLY

Standard self-locking formats



01

Gently pre-fold each scored edge. Keep the fold at 90 degrees or less and avoid crushing the board.



02

Bring the inner wall panels towards the centre of the box.



03

Fold the side panels inward and seat their locking tabs in the base slots.



04

Fold the remaining panels. Tuck the lid wings into the side panels.



05

Check that the walls sit square and every tab is seated before use.